

■ Dry Fit Like a Pro Checklist

- Do all floor levels align properly?
- Are walls straight, flush, and square at the corners?
- Do door and window openings match the correct pieces?
- Have you labeled each part in pencil on the back or hidden edge?
- Did you tape pieces together with painter's tape to test stability?
- Have you checked for warped wood that may need clamps or sanding?
- Did you take pictures for reference before disassembling?
- Are you working one level at a time, not forcing the whole house at once?

■ Tip: Slow builds are strong builds. Dry fitting saves time, wood, and your sanity.